

Rittal – The System.

Faster – better – everywhere.

HD Nivellierfüße
HD Levelling Feet
HD Pieds de nivellement



4000.240
4000.250

Montage- und Bedienungsanleitung
Assembly and operating instructions
Notice d'emploi et de montage



ENCLOSURES

POWER DISTRIBUTION

CLIMATE CONTROL

IT INFRASTRUCTURE

SOFTWARE & SERVICES

FRIEDHELM LOH GROUP




DE


EN

FR



Lieferumfang/Scope of supply/ Composition de la livraison





			Best.-Nr. Model No. Référence
	M12	4 x	4000.240
	M12	4 x	4000.250
	M10	4 x	



F max – Siehe Belastungsbroschüre TS8

F max – See Load indications TS8

F max – voir brochure «Load indications TS8»
(disponible en version anglaise seulement)









DE

EN

FR

Montage Nivellierfüße/Assembly levelling feet/ Montage des pieds de nivellement



Rittal – The System.

Faster – better – everywhere.

- Enclosures
- Power Distribution
- Climate Control
- IT Infrastructure
- Software & Services

You can find the contact details of all Rittal companies throughout the world here.



www.rittal.com/contact

RITTAL GmbH & Co. KG
Postfach 1662 · D-35726 Herborn
Phone +49(0)2772 505-0 · Fax +49(0)2772 505-2319
E-mail: info@rittal.de · www.rittal.com

04.2018/D-0000-000000312Rev01

ENCLOSURES

POWER DISTRIBUTION

CLIMATE CONTROL

IT INFRASTRUCTURE

SOFTWARE & SERVICES

