Rittal - The System.

Faster - better - worldwide.




Assembly and operating instructions



VERTICAL FOAM BAFFLE TO RAIL CONFIGURATION

- 1. REMOVE PAPER BACK TO EXPOSE TAPE ON FOAM BAFFLE.
- 2. ALIGN FRONT EDGE OF FOAM BAFFLE WITH FRONT EDGE OF EIA RAIL AND PRESS FIRMLY.



FOAM BAFFLE INSTALLATION INSTRUCTIONS BAYING BETWEEN RAIL CONFIGURATION



Rittal – The System.

Faster - better - worldwide.

- Enclosures
- Power Distribution
- Climate Control
- IT Infrastructure
- Software & Services

The Rittal Corporation is the U.S. subsidiary of Rittal GmbH & Co. KG and manufactures the world's leading industrial and IT enclosures, racks and accessories, including climate control and power management systems for industrial, data center, outdoor and hybrid applications. For more information about Rittal and its products, please visit www.rittal-corp.com or call 1-800-477-4000.

CLIMATE CONTROL

Rittal Corporation 1 Rittal Place • Urbana Ohio 43078 • USA Phone: 937-399-0500 • Fax: 800-477-4003 • Toll-free: 800-477-4000 Email: rittal@rittal-corp.com • Online: www.rittal-corp.com

Rittal Systems Ltd. 6485 Ordan Drive • Mississauga Ontario L5T 1X2 • Canada Phone: 905-795-0777 • Fax: 905-795-9548 • Toll-free: 800-399-0748 Email: marketing@rittal.ca • Online: www.rittal.ca

