


Enclosures

Support arm system CP-XL

Tilting adaptor 10° CP-XL

Catalogue 33, page 163


CP 6023.010



Enclosure attachment CP-XL, round

Catalogue 33, page 163


CP 6130.610



Enclosure attachment CP-XL, rectangular

Catalogue 33, page 163


CP 6130.510



Housing coupling CP-XL

Catalogue 33, page 163


CP 6130.010




Angle coupling 90° CP-XL

Catalogue 33, page 163


CP 6040.010




Mounting cut-out
Enclosure CP-XL



Top-mounting is only possible as shown in the diagrams below (without intermediate hinge).



- 1** Angle coupling CP 6040.0X0
- 2** Support section CP-XL
- 3** Wall/base mounting bracket CP 6160.0X0




- 1** Angle coupling CP 6040.0X0
- 2** Support section CP-XL
- 3** Top-mounted joint CP 6170.0X0



Support section CP-XL, closed and open

Catalogue 33, page 163

Support section
closed



Support section
open






Length mm	Support section	
	Closed	Open
	Model No. CP	
500	6050.500	6050.000
1000	6100.500	6100.000
2000	6200.500	6200.000

Angle piece 90° CP-XL

Catalogue 33, page 163

CP 6140.010

CP 6180.010




Enclosures

Support arm system CP-XL

Intermediate hinge CP-XL

Catalogue 33, page 163


CP 6120.010



Top-mounted joint CP-XL

Catalogue 33, page 163


CP 6170.010



Wall-mounted hinge CP-XL

Catalogue 33, page 163


CP 6110.010



Wall/base mounting CP-XL

Catalogue 33, page 163

CP 6160.010



Rotation range restrictor CP-XL

Catalogue 33, page 163

CP 6110.100

Adjustable swivel area:

