## Rittal – The System.

Faster - better - everywhere.





# CP 6016.200 Enclosure connectors

State: 11.09.2025. (Source: rittal.com/hr-hr)



## CP 6016.200 - Enclosure connectors Adjustable

For use between Command Panels, terminal boxes, compact enclosures and horizontal or vertical surfaces. Pre-mount the connector halves on both sides, screw together and secure with a locking screw, and/or adjust the angle of rotation.



#### **Features**

| ls, terminal boxes, compact cal surfaces. Pre-mount the |
|---|
| crew together and secure with a ngle of rotation.       |
|   |
|   |
|   |
|   |
| nged for standard, commercially<br>50 mm).              |
| ncrements.  |
|   |
|   |
|   |
|   |
|   |
|   |

© Rittal 2025 2

#### **Features**

| ETIM 9     | EC002622 |  |
|------------|----------|--|
| ECLASS 8.0 | 27189263 |  |

© Rittal 2025 3