


Swing frame, large

Without trim panel, for 600 mm and 1200 mm wide enclosures



Height units	22 HE	31 HE	36 HE	40 HE	45 HE
Model No. SR	2322.700	2331.700	2336.700	2340.700	2345.700
For enclosure height mm (or higher)	1200	1600	1800	2000	2200
H1 mm	1061.5	1461.5	1684.5	1861.5	2084.0
H2 mm	981.5	1381.5	1604.0	1781.5	2004.0

Installation depth T max. = mm for dimension D¹⁾ of at least 49 mm

Enclosure width mm	600	1200	1200
Internal mounting	Centre	Left or right	Left and right
Enclosure depth mm	1 T max. 400 185 500 185 600 185 800 185	1 T max. 295 395 495 695	1 T max. 295 365 365 365


¹⁾ D = Distance from the inner edge of the door to the front edge of the swing frame may be installed deeper on a 25 mm pitch pattern

System accessories


482.6 mm (19") installation system

13 examples for TS, SE


Full installation




600 mm front



1200 mm front



1200 mm front with width divider



1200 mm set back with width divider


- 1 Installation kit for 600 mm wide enclosures
- 2 Installation kit for 1200 mm wide enclosures
- 3 TS punched section with mounting flange 23 x 73 mm for the inner mounting level corresponding to the enclosure depth
- 4 PS punched section without mounting flange in the respective enclosure depth in conjunction with support bracket PS
- 5 TS punched rail 18 x 38 mm in the corresponding enclosure depth¹⁾
- 6 Width divider (left-hand or right-hand angle)¹⁾

¹⁾ Not possible with CM


Notes:

- Height compensation between the 25 mm pitch pattern of holes in the enclosure and the height units of the swing frame is achieved by the upper installation kit
- Partial installation at the bottom matches partial installation at the top
- CM only supports full installation at the front


Partial installation, top




600 mm front



600 mm set back




1200 mm front




1200 mm set back


Partial installation, centre




600 mm front



600 mm set back



1200 mm front



1200 mm set back

Side installation

(only for TS)

With an enclosure depth of 600 mm, side installation of a large swing frame is identical to installation parallel to the front. For ease of access to the swing frame, we recommend the hinges for the TS side panel.

