

# System accessories

## 482.6 mm (19") installation system

#### Swing frame, large

Without trim panel, for 600 mm and 1200 mm wide enclosures Catalogue 33, page 735





Height units	22 U	31 U	36 ∪	40 U	45 U
Model No. SR	2322.700	2331.700	2336.700	2340.700	2345.700
For enclosure height mm (or higher)	1200	1600	1800	2000	2200
H1 mm	1061.5	1461.5	1684.5	1861.5	2084.0
H2 mm	981.5	1381.5	1604.0	1781.5	2004.0


Installation depth T max. = mm wit	th dimension D <sup>1)</sup> of at least 49 mm		
Enclosure width mm	600	1200	1200
	D T max.	D T max.	T max.
Installation	central	left or right	left and right
Enclosure depth mm 400 500 600 800	T max. 185 185 185 185	T max. 295 395 495 695	T max. 295 365 365 365

<sup>1)</sup> D = Distance from the inner edge of the door to the front edge of the swing frame may be installed deeper on a 25 mm pitch pattern.


## System accessories


### 482.6 mm (19") installation system


#### 13 examples for TS





front






















set back





Partial installation, centre



- 1 Installation kit for 600 mm wide enclosures
- 2 Installation kit for 1200 mm wide enclosures
- 3 TS punched section with mounting flange 23 x 73 mm for the inner mounting level in the respective enclosure depth, for installation in ES = PS punched sections with mounting flanges
- 4 PS punched section without mounting flange in the respective enclosure depth in conjunction with support bracket PS
- TS punched rail 18 x 38 mm in the corresponding enclosure depth<sup>1)</sup>
- 6 Width divider (left-hand or right-hand angle)1) 1) Not possible with ES, CM.

- Height compensation between the 25 mm pitch pattern of holes in the enclosure and the height units of the swing frame is achieved by the upper installation kit.
- Partial installation at the bottom matches partial installation at the top.CM only supports full installation at the front.

#### Side installation

With an enclosure depth of 600 mm, side installation of a large swing frame is identical to installation parallel to the front. For access to the swing frame we recommend the hinges for the TS side panel, see Catalogue 33, page 569.

